




















Deluxe Kitchen / Utility Cart (R)

Assembly Instructions

Model 80690 - WHITE
Model 80696 - BLACK

HARDWARE

- A** JCBC

M6 x 35mm x10
- B** THCB Screw

M4 x 16mm x4
- C** PHCB Screw

M3.5 x 15mm x4
- D** Wood Screw

M4 x 30mm x12
- E** THMS Screw

5/32 x 22mm x6
- F** Allen Wrench

M4 x1
- G** 'Z' Bracket

G-142 x4
- H** Door Hinge

L-115 x4
- J** 2" Stopper Caster

x2
- K** Wood Dowel

M7.8 x 30mm x2
- L** Metal Handle

x3
- M** Magnet

x2
- N** 2" Caster

x2
- P** Wood Button

M13.5 x10
- R** Wood Screw

M4 x 25mm x4
- S** Drawer Front Block

Left & Right x2



1 Side Panel - (Left & Right) x2

2 Bottom Front Support x1

3 Bottom Back Support x1

4 Base Panel x1

5 Back Panel x1

6 Top Back Support x1

7 Door Panel (Left & Right) x2

8 Top Shelf x1

9 Top Panel x1

10 Drawer Front x1

11 Drawer Side x2

12 Drawer Base x1

13 Drawer Back x1

14 Drawer Guide x 2pcs


IMPORTANT! DO NOT TIGHTEN SCREWS OR BOLTS UNTIL COMPLETELY ASSEMBLED!!

Customer Service 0607 - 652 7321




Deluxe Kitchen / Utility Cart (R) Assembly Instructions

Model 80690 - WHITE
Model 80696 - BLACK



IMPORTANT! DO NOT TIGHTEN SCREWS OR BOLTS UNTIL COMPLETELY ASSEMBLED!!

Customer Service 0607 - 652 7321



IMPORTANT! DO NOT TIGHTEN SCREWS OR BOLTS UNTIL COMPLETELY ASSEMBLED!!

Customer Service 0607 - 652 7321